


Charge Powerbank



Choose left or right USB-C port



International:
www.sandberg.world/mt/manual/320-43

Saver Powerbank 27000

Item no. 320-43

www.sandberg.world

info@sandberg.world

Sandberg A/S

Bregnerødvej 133D,


3460 Birkerød, Denmark

Made in China



NOTE: If not used regularly, please recharge the powerbank at least every 3 months to maintain optimal performance.

Charge devices



Example of use